

Printing Frame Tags

Frame Tag Hardware



Zebra GK420t only at 1 station.



HONEYWELL 1902GSR-2USB-5

Frame Tag Software Application



1. Access the Tag Printing Application from any of the retail workstations
2. Click to enter your UPC
3. You can use the Honeywell Scanner to scan existing frame tags or type out the UPC in the box to print a new tag or replacement tag for re-tagging activities

Frame Tag Printing

UPC: Print

Zebra Printer Troubleshooting

Status Light Descriptions

| LED Color | Printer Status |
|------------------------------------|------------------|
| Off | Off |
| Solid Green | On |
| Flashing Green | Normal Operation |
| Double Flashing Green | Paused |
| Flashing Amber | Paused |
| Solid Amber | Stopped |
| Flashing Red | Stopped |
| Alternately Flashing Green and Red | Needs Service |

Manual Calibration

1. Make sure media is loaded
2. Turn on the printer power
3. Press and hold the Feed button until the green status light flashes once, then twice and then continuing until the flash groups reach the group of seven flashes. Release the Feed button
4. The printer will set the media sensor for the label backing being used. After it is done making the adjustment, the roll will automatically feed until a label is positioned at the printhead. A profile of the media sensor setting will print. Upon completion, the printer will save the new setting in memory and the printer is ready for normal operation
5. Press the Feed button. One entire blank label will feed

For additional support contact TeamVision Store Support 1-833-467-4243